
# JY-16 Timer Board





- 1. Please press button "S4", and then please use button "S1" and button "S2" to set up **PRICE**.
- Please press button "S4", and then use button "S1" and "S2" to set up TIME for FIRST 2 NUMBER (00:--)
- 3. Please press button "S4", and then use button "S1" and "S2" to set up TIME for LAST 2 NUMBER (--:00)
- 4. Please press button "S4", and then use button "S1" and "S2" to set up **PRICE OF GIVEN TIME.**
- Please press button "S4". Use button "S1" and "S2" to set up GIVENTIME for FIRST2NUMBER (00:--)
- 6. Please press button "S4". Use button "S1" and "S2" to set up GIVENTIME for LAST2NUMBER. (---:00)
- 7. Please press button "S4". Use button "S1" and "S2" to set up TIME for WARNING SOUND Default Is 30seconds.

#### Mode Setting

- 1. Please hold on button "S1" and "S2" to get into MODESETTING.
- 2. Please use button "S1" and button "S2" to set up CODE for FIRST MODE.
- 3. Please press button "S4" after setting.
- 4. Please repeat step 2 and step 3 for setting rest mode.

#### **Code Introduction**

#### **Operating Mode**

01:01 – Time Counts down without pressing button 01:02 – Time Counts down by pressing button

### Time Type

02:03 – Minute: Second 02:04 – Hour : Minute

#### Memory Mode

03:05 – Continue counting time after power off and on 03:06 – Reset time and value after power off and on

#### **Time for Reset Automatically**

04:??- 1-30 minutes are adjustable.

## SOURCEWELL DEVICES PVT. LTD.

Formerly Known as EMAAR IMPEX PVT. LTD. 302/303, Diamond Plaza, Lamington Road, Mumbai-400 004 INDIA Tel.:+91-22-43 688 688 sales@sourcewell.in www.sourcewell.in

# JY-16 Timer Board



**Description:** Time and price will be reset automatically if user does not choose any function after the user insert coins.

### **Default**

Operating Mode : 01:01 Time Type: 02:03 Memory Mode: 03:06 Time for RESET AUTOMATICALLY: non-functioned

## SOURCEWELL DEVICES PVT. LTD.

Formerly Known as EMAAR IMPEX PVT. LTD. 302/303, Diamond Plaza, Lamington Road, Mumbai-400 004 INDIA

Tel.:+91-22-43 688 688 sales@sourcewell.in www.sourcewell.in